

GROUND ZERO[®]

GERMAN ENGINEERING

GZDM Doorkit application instructions

Required tools:

- Damping roller (e.g. GZDR 1000)
- Cutter and scissors
- Working gloves
- Grease cleaner and fabric
- Mechanic tools for disassembling the door trim



Attention!

As a precaution, always wear working gloves to protect your hands from injury when cutting and applying the damping materials!

Step 1: Disassemble the door trim to uncover the panel surface*

Step 2: Clean the surface of the door panel from grease, grime, silicone and wax - remaining grease reduces the adhesive force of the damping material!



Step 3: Cut the anti-vibrating GZDM 3750AB-SILVER (8 sheets included) to fitting piece

Step 4: Loosen the carrier layer and stick the fitting pieces to the cleaned door panel



GROUND ZERO®

GERMAN ENGINEERING

Step 5: Cut the polyethylene noise damping foam (2 sheets included) to fitting pieces

Step 6: Loosen the carrier layer and stick the fitting pieces to the black aluminum surface of GZDM 3750AB-SILVER as topping layer to reduce standing waves inside the door



Step 7: Clean the surface of the back side of the door trim from grease and grime

Step 8: Cut the GZDF 1500SA sound absorbing formed foam (4 sheets included) to fitting pieces

Step 9: Loosen the carrier layer and stick the fitting pieces to the back side of the door trim



Step 10: Re-assemble the door trim and check the functions of the power window and switches



*If you have no experience in car parts disassembling, please contact your car audio dealer

